





02 AIR SYSTEMS



02 AIR SYSTEMS

Boeing 737 Next Generation Air Systems

Bleed air system

Normal Procedures

- Two-pack APU ground operations
- External air cart connection
- After engine start
- No-engine bleed takeoff & landing

The control panel shows the following configuration for Normal Procedures:

- APU BLEED switch: OFF
- PACKS switch: AUTO
- ISOLATION VALVE switch: OPEN
- WING ANTI ICE switch: OFF/AUTO/HIGH
- RECIRC FAN switch: AUTO
- DUAL BLEED switch: OFF
- RH DOOR FULL OPEN switch: ON
- LH DOOR FULL OPEN switch: ON
- TEST switch: OFF
- RESET switch: OFF
- TRIP switch: OFF
- APU BLEED switch: OFF
- ON/OFF switch: ON

Boeing 737 Next Generation Air Systems

Bleed air system

Normal Procedures

Two-pack APU ground operations

APU BLEED ... ON
LEFT PACK ... AUTO
ISOLATION VALVE ... OPEN
RIGHT PACK ... AUTO

The control panel shows the following configuration for Normal Procedures with APU BLEED ON:

- APU BLEED switch: ON
- PACKS switch: AUTO
- ISOLATION VALVE switch: OPEN
- WING ANTI ICE switch: OFF/AUTO/HIGH
- RECIRC FAN switch: AUTO
- DUAL BLEED switch: OFF
- RH DOOR FULL OPEN switch: ON
- LH DOOR FULL OPEN switch: ON
- TEST switch: OFF
- RESET switch: OFF
- TRIP switch: OFF
- APU BLEED switch: ON
- ON/OFF switch: ON

Boeing 737 Next Generation Air Systems

Bleed air system

Normal Procedures

External air cart connection

BATTERY ... ON

RECIRC FAN ... AUTO
ISOLATION VALVE ... OPEN
APU BLEED ... OFF
PACKS ... AUTO

The control panel shows the following configuration for Normal Procedures with BATTERY ON:

- APU BLEED switch: OFF
- PACKS switch: AUTO
- ISOLATION VALVE switch: OPEN
- WING ANTI ICE switch: OFF/AUTO/HIGH
- RECIRC FAN switch: AUTO
- DUAL BLEED switch: OFF
- RH DOOR FULL OPEN switch: ON
- LH DOOR FULL OPEN switch: ON
- TEST switch: OFF
- RESET switch: OFF
- TRIP switch: OFF
- APU BLEED switch: OFF
- ON/OFF switch: ON

Boeing 737 Next Generation Air Systems

Bleed air system

Normal Procedures

After engine start

PACKS ... AUTO
APU BLEED ... OFF
ISOLATION VALVE ... AUTO

The control panel shows the following configuration for Normal Procedures after engine start:

- APU BLEED switch: OFF
- PACKS switch: AUTO
- ISOLATION VALVE switch: AUTO
- WING ANTI ICE switch: OFF/AUTO/HIGH
- RECIRC FAN switch: AUTO
- DUAL BLEED switch: OFF
- RH DOOR FULL OPEN switch: ON
- LH DOOR FULL OPEN switch: ON
- TEST switch: OFF
- RESET switch: OFF
- TRIP switch: OFF
- APU BLEED switch: OFF
- ON/OFF switch: ON

Boeing 737 Next Generation Air Systems

Bleed air system

Normal Procedures

No-engine bleed takeoff & landing

Before takeoff / during descent

RIGHT PACK ... AUTO
ISOLATION VALVE ... CLOSED
LEFT PACK ... AUTO
LEFT ENGINE BLEED ... OFF
APU BLEED ... ON
RIGHT ENGINE BLEED ... OFF

The control panel shows the following configuration for Normal Procedures before takeoff/during descent:

- APU BLEED switch: ON
- PACKS switch: AUTO
- ISOLATION VALVE switch: CLOSED
- WING ANTI ICE switch: OFF/AUTO/HIGH
- RECIRC FAN switch: AUTO
- DUAL BLEED switch: OFF
- RH DOOR FULL OPEN switch: ON
- LH DOOR FULL OPEN switch: ON
- TEST switch: OFF
- RESET switch: OFF
- TRIP switch: OFF
- APU BLEED switch: ON
- ON/OFF switch: OFF

Boeing 737 Next Generation Air Systems

Bleed air system

Wing-Body Overheat







Kiváltó körülmény:
Szivárgás a bleed air duct rendszerben
Szenzorokon keresztül jut el az információ az air cond. and bleed air control panel-en található WING-BODY OVERHEAT annoucniator lámpákhoz.

The diagram illustrates the locations of wing-body overheat sensors:

- LEFT LIGHT Sensors located:**
 - ① Left engine strut.
 - ② Left inboard wing leading edge.
 - ③ Left-hand air conditioning bay.
 - ④ Keel beam.
 - ⑤ Bleed duct from APU.
- RIGHT LIGHT Sensors located:**
 - ⑥ Right engine strut.
 - ⑦ Right inboard wing leading edge.
 - ⑧ Right-hand air conditioning bay.

The control panel has two switches labeled "WING-BODY OVERHEAT" with "OPEN" and "TRIP" positions.

02 AIR SYSTEMS



02 AIR SYSTEMS

Air conditioning system

Non-normal conditions

Duct overheat




- Air mix valves move to full cold
- Set cooler temperature
- Push trip reset switch

Amennyiben a duct hőmérséklet gyorsan elkezd nőni, vagy az air mix valve FULL HOT állásba vált, az adott hőmérsékletszabályozó egység üzemképtelen.

Teendők:


← A kapcsolódó temperature selector MANUAL üzemmódba állítása



Air conditioning system

Non-normal conditions

Pack trip off



- Air mix valves move to full cold
- Pack valve closes
- Select higher temp on TEMP SELECTOR
- Press TRIP RESET switch

Pressurization system


System components



Pressurization system

Controls & Indicators

Cabin altitude panel




(fwd overhead panel)

1 CAB Alt, DIFF Press indicator
 2 Cabin rate of climb indicator
 3 ALT HORN Cutout

Pressurization system

Controls & Indicators




1 AUTO FAIL light
 2 OFF SCHED DESC light
 3 FLT ALT indicator
 4 Flight altitude selector
 5 LAND ALT indicator
 6 Landing altitude selector
 7 MANUAL light
 8 ALTN light
 9 Outflow valve pos indicator
 10 Outflow valve switch
 11 Pressurization mode selector
 12 CAB/FLT ALT placard

Pressurization system





Cabin pressure control

Üzemmódk



- **AUTO** (Automatic)
- Automatikus nyomásszabályozás; normál üzemeltetés.
- **ALTN** (Alternate)
- Automatikus nyomásszabályozás; alternatív rendszer.
- **MAN** (Manual)
- Manuális vezérlés egyenáramú motor segítségével.



02 AIR SYSTEMS



02 AIR SYSTEMS



Köszönöm a figyelmet!

Copyright 2005 © Malev Virtual Training Division. All rights reserved.

Elérhetőségek:

Internet: <http://www.malev.hu/virtual>

E-mail: training@virtualairlines.hu

Előadó: Hegedűs Zoltán